

# HydroBlock™

## Installation Guide

The following should be used as a guide only. Always consult local codes for specific requirements regarding trench drain installation in your area before beginning.

Use caution. Wear gloves, safety glasses, and other protective equipment during handling and installation.



Construct concrete footer using Earth Moistened (Low Slump) Concrete. 1" Slump. Width and depth of footer should be made according to load requirements. (Refer to project installation detail)



Before fitting sections together, apply lubricant to both spigot end and socket ends.



Align the spigot and socket of the sections to be joined



The HydroBlock installation aid/tool can be used to facilitate pulling sections completely together.



After sections are joined, verify they are set at the intended elevation, making adjustments as necessary.



When properly in place, concrete should be placed around the feet of the sections. Once concrete stiffens, contractor can finish encasement with the specified paving materials.

Supply

Drainage

Support

Specialties

[www.siouxchief.com](http://www.siouxchief.com)

TAKE THE FIELD.

